easy mobile

GO EASY, GO MOBILE.

WIRELESS CHARGING STAND

POWER STAND 10

USER MANUAL

Thank you for your confidence in purchase another product with Easy Mobile quality.

Please read this manual in detail before using the product and keep it for your reference.

The Power Stand 10 is a foldable wireless charger. It uses efficient technology, modern design, 2 transmitters, high efficiency and much more stable in performance.

PRODUCT DESCRIPTION

1. 2 Transmitters
2. Dashboard Loading
3. Support plate
4. LED indicator
5. Port Loading
6. Support telephone

SPECIFICATIONS

Fast charge input: 9V / 1.7A 5V / 2A
Fast charge output: 10W
Charging efficiency: 75%
Meet IQ standards: WPC1.2.4
Wireless charging standards
Charging distance: = 8mm

Protective measures: Current overload control temperature control, short circuit prevention, effective detection of metal interference and other interference

Features: Support 10W / 7.5W compatible charging. When the telegone battery is full, the green light will always be on.

INSTRUCTIONS

1. When turned on, the red light will always be on.
2. Put the phone on, the green light will be blinking. So it's working
3. Store the phone, the red light is still on, the green light off. Stop working.
4. When an abnormality or metal interference, the red light will flash or will be turned off automatically to protect yourself.
5. When the phone is fully charged, the green light will always stay on.

ATTENTION

1- Please use a qualified USB power adapter. For a faster and more efficient charging experience, it is recommended to use a QC2.0 or QC3.0 compatible adapter.

2- Do not place metallic objects or this manual on the charger, as this may cause damage or malfunction to the charger.

3- If the receiving or transmitting end is overheated during charging, stop charging and remove the charging product. After cooling, try charging again.

4- The equipment that needs to be loaded must be within the 8mm distance, otherwise it cannot be loaded.

5- When charging the phone, place it in the center of the wireless charger.

6- Keep the wireless charger away from water and other liquids.

SECURITY INSTRUCTIONS

1. Do not force the power cord to avoid breakage or loss of efficiency of the energy.
2. Do not disassemble it yourself, do not put it in the fire, in the water.
3. Do not use in high temperature environments, moisture or corrosion.

COMMON QUESTIONS

Q: The phone is not charged.
A: The phone is not aligned with the area charge sensor or the receiving coil is not installed correctly.

P: Charging heating.
A: It is normal for the receiver or transmitter to generate heat during wireless charging.

Q: Intermittent cell phone charging.
A: Insufficient charging current or unstable voltage. It may be the USB charging tip, adapter and or data cable does not meet the standard. Please use qualified adapter. The loading position is not correct, please adjust the position.

Q: The indicator light is normal, but the phone cannot be charged.
A: The failure of the phone's wireless charging sensor / receiver is recommended to update or repair.

Q: Loading slowly.
A: The electric current is different between the form of the cordless phone charger.

A: Please reduce the cell phone standby program when charging.

Within 12 months from the date of purchase of the product, if there is a quality problem as defined in the warranty, please contact us at any time.

CE RoHS compliant

easy mobile
GO EASY, GO MOBILE.

easym.com.br
/easymobile.br
@easy.mobile

Product support:
E-mail: **support@easym.com.br**