

easy


mobile

GO EASY, GO MOBILE.



RUNNER BT
WIRELESS EARPHONE

USER MANUAL



- A Previous Media Command / Volume Up
- B Multifunction button
- C Next media button / Volume down
- D LED indicator
- E Microphone
- F Micro USB port for charging battery

USE INSTRUCTION

1. CHARGE THE “Runner BT”

- a) Plug the earphone charging cable into a powered USB port and the Micro-USB port of the earphone. The red light will stay lit while charging and turn blue when fully charged.


2. PAIR WITH YOUR DEVICE

- a) When the earphone is off, press and hold the multifunction button for 5 seconds until you see the red and blue lights flashing in an alternating manner. The earphone will say “Ready to pair.” Pairing mode will remain active for 2 minutes or until paired.
- b) Open the Bluetooth menu on the device you wish to pair. Some devices require you to select “search for devices” or “add new device” in order to create a Bluetooth pairing.
- c) Wait until you see “Runner BT” on your device screen.
- d) Select “Runner BT” on your device and follow any further prompts to pair. Use 0000 if a pin is required. Once pairing is complete and a connection is established, the earphone will say “Pairing Complete.”

3. CONFIGURE FOR YOUR EARS

a) Ear Tips: Select Correct Size

If your music sounds tinny or lacks bass, try different ear tips.



Runner BT includes 4 sets of ear tips to ensure you get the best fit, comfort, and sound.


b) Identify the Right and Left Channel

They are not interchangeable, and the cable must be worn over-the-ear.

c) Configuring the Memory Wire

- I. Straighten the memory wire.
- II. Put the earphones in your ears.
- III. Ensure the ear tips seal with your ear canals and the earphone is flush in the ear.
- IV. Bend the memory wire tightly around the back of your ears to achieve a conforming a fit.
- V. (Optional): For a more secure fit, remove the earphones and continue to bend the memory wire in the same direction to make it more secure around the top of the ear when worn.


d) **Use the sliding cable cinch to reduce cable slack for the most secure and comfortable fit.**




a. Install ear tips as shown.
Make sure ear tip is installed tightly before use.



b. Straighten the memory wire and put the earphones in your ears.



c. Bend the memory wire around the back of your ears.



d. Reduce cable slack with sliding cable cinch for the most secure and comfortable fit.

BLUETOOTH FUNCTIONALITY

1. TURNING ON AND OFF

- a) To turn on, press and hold the multifunction button for approximately 5 seconds. The earphone will say "power on" and the red indicator light will flash 3 times. The blue indicator light will blink every 1 seconds when on but not connected, and every 8 seconds when on and connected. If not connected with a device, auto shutoff occurs after 5 minutes.
- b) To turn off, press and hold the multifunction button for approximately 5 seconds. Keep holding the button until you hear "power off." The red and blue light will blink 3 times.

2. PAIRING

It is only necessary to pair your earphone once with each device.

3. CONNECTED

Once the earphone is turned on, it will automatically connect with the last paired Bluetooth device that is on and within range. If the earphone is not connected automatically, go to the Bluetooth menu on your device and select "Runner BT" from the Bluetooth device list to connect. Note: The earphone will only connect with one device at a time.

4. CONTROL

The earphone can control media and phone calls from a smartphone or tablet.

Note: A short-press of a button takes less than 1 second and a long-press takes approximately 2 seconds. A double-press is two short-presses.

The earphone will beep to indicate when a phone function is successful.

a) CONTROLLING MEDIA AND VOLUME

(Note: volume adjustments are only possible during a call or when media is playing):

- I. Increase volume: long-press the (+) button.
When maximum volume is reached, the earphone will beep.
- II. Decrease volume: long-press the (-) button.
When minimum volume is reached, the X6 will beep.
- III. Play/Pause: short-press the multifunction button.
- IV. Skip to the previous track: short-press the (+) button.
- V. Skip to the next track: short-press the (-) button.

b) CONTROLLING PHONE CALLS:

- I. Answering an incoming call: short-press the multifunction button.
- II. Hang-up a call: short-press the multifunction button.
- III. Reject a call: long-press the multifunction button.

IV. On a call, another call incoming:

- a. End active call, answer incoming call: short-press the multifunction button.
- b. Place active call on hold, answer incoming call: double-press the multifunction button.
- c. On a call, another call on hold: End active call, switch to second call, short-press the multifunction button.

V. Double press to call the last call.

CHARGING

Plug the charging cable into a powered USB port and the Micro-USB port of the earphone.

The red light will stay lit while charging and turn blue when fully charged.



easy
mobile
GO EASY, GO MOBILE.

 easym.com.br

 [/easymobile.br](https://www.facebook.com/easymobile.br)

 [@easy.mobile](https://www.instagram.com/easy.mobile)

Product Support:

Email: support@easym.com.br