easy mobile

GO EASY, GO MOBILE.

IP65 RESISTANT WATER AND DUST

ACTIVE BOX
WIRELESS SPEAKER

USER MANUAL

ACCESSORIES

1x Active B ox Bluetooth Speaker
1x User Manual
1x USB Charging Cable
1x AUX 3.5mm Audio Cable

HIGHLIGHTS

The Active Box is a compact Bluetooth speaker that can be wirelessly connected to Bluetooth devices such as smart phones, tablets, and computers to playback any music collection stored on them. Thanks to the powerful battery and a passive radiator, the speaker delivers a long(6 to 8 hours lasting)playing experience with a powerful BASS. This makes the Kraken-S the perfect companion for you wherever you go.

BLUETOOTH CONNECTION

Turn the speaker on by pressing the power for several seconds, then the blue led flashes quickly. The speaker now has entered the Bluetooth pairing mode.

CONNECT TO MOBILE PHONES/TABLET PCs/COMPUTERS

1. Activate your phone's Bluetooth.
2. Go to your phone's Bluetooth settings, scan for new Bluetooth devices.
3. Upon device found (Kraken-S), click the device name and pair with it.
4. If your phone ask for pairing code , please enter ”0000” and confirm it.
5. After successful pairing, the speaker will make a prompt sound and the LED light stays blue.

Note:

Pairing time is varied with different mobile phones. It only needs pairing at the first time and it will auto connect the devices which have already been paired before(The speaker only can remember the last 8 paired devices' names).

AUX AUDIO-IN CONNECTOR

The speaker also features 1x AUX audio in port, simply connect the speaker with your non-Bluetooth mobile phone/MP3 player/PC/ laptop with the 3.5mm jack audio cable. The green indicator light will be on, then you can play music via wired connection.

Low power indication

The speaker will have voice hint to remind you to charge if battery is low(battery only left 10%). Users need to charge the speaker timely.

CHARGING AND COMPUTER CONNECTION

Connect the micro USB charging cable to a computer or USB charger to charge the speaker.

SPECIFICATIONS

Speaker Interfaces

Audio input connector: 3.5mm

AUX cable: support aux external audio input

Charging interface: Micro USB; Input 5V



Dimensions and Basic Parameters

Length: 98mm ± 0.5mm

Width: 50± 0.5mm

Height: 90mm ± 0.5mm

Material: ABS+TPU

Weight: 286g ±10g

ELECTRICAL SPECIFICATIONS

- Bluetooth Compatibility: It is compatible with Bluetooth 4.1 Class II and supports A2DP V1.2, AVRCP V1.4 profiles agreement.
- Transmission distance: up to 10 m
- Sound track: Single track
- Signal to noise ratio S / N: ≥75dB
- Frequency Range: 160Hz-20KHz
- Distortion THD: ≤ 1%
- Speaker unit: outer diameter 50mm, inner magnet, 4Ω, 5W x 1

Parameters of power

- Rated voltage: 3.7V DC
- Battery: Built-in lithium battery, 3.7V/1500mAh
- Charging Voltage/Current: 5V ± 0.25V / 0.5A
- Charging time: 3~4 hours
- Playing time: 6~8 hours

Powering ON / OFF	Long press ⏻ to power on / off.
Answering a call	During an incoming call, short press ⏯ key to answer the phone, short press ⏯ again hand up phone and back to play music.
Ending or refuse a call	Short press ⏯ key to end the call or long press ⏯ to refuse the call.
Make a call	Long press ⏯ to call the last dialed umber.
Play/Pause	Short press ⏯ to adjust.
Volume - or +	Short press +/- to adjust.
Next/Previous	Long press + to the next. Long press – to the previous.
Disconnect current Bluetooth	Long press "+" and "-" to disconnect the current Bluetooth connection and searching for another new device and pairing.

Note:

1. Under Bluetooth mode when the 3.5mm audio plug is inserted, the speaker will switch to line in status automatically;
2. Please turn off the speaker if you don't use it to prevent power drain.

LED status

1. Bluetooth status: Blue lights flashes for pairing. Blue light keeps on for connection status.
2. Line in mode: green light on.
3. Charging status: red light on.
4. Charging completed: red light off, green light on.

WORKING TEMPERATURE	STORAGE CONDITION
Temperature: 0° C ~ 40° C	Temperature: -30° C ~ 60° C
Humidity: 0% ~ 85% RH	Humidity: 0% ~ 90% RH

TROUBLE SHOOTINGS

1. My mobile phone can't find any new Bluetooth devices?

a) Make sure the Bluetooth speaker has entered pairing mode;

b) Ensure the speaker is within the effective working range;

2. Bluetooth devices can't pair up

a) Make sure your mobile phone allows new connection, did not reach the maximum allowed connection number, please refer to your mobile's user manual

b) Make sure the pairing password entered is "0000'. If you are using a Bluetooth transmitter device, pleaseensure the responding password of your Bluetooth transmitter supports "0000" code.

3. My mini speaker does not play music / answer call when it connected to a Bluetooth mobile phone?

a) Make sure your Bluetooth mobile phone supports A2DPand HSF (hands-free) profile;

b) Ensure your Bluetooth cell phone is within effective working range.

4. When paired with my computer, windows ask for new driver? Can you supply?

a) We can't supply. The Bluetooth A2DP/HSF drivers may require playing stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speaker. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

a) When you are using 3.5mm AUX audio in connection, you can't pause, change volume or skip tracks with the buttons on the speaker;

b) This feature needs the Bluetooth devices paired with the speaker to support AVRCP (Audio/Video Remote Control Profile). Please make sure your cell phone or other Bluetooth device supports AVRCP.

SAFETY NOTICES

Read the following recommendations before using the Bluetooth speaker.

a) Keep it dry and don't take it to damp places to avoid the product's internal circuit being affected.

b) Keep the product away from direct sunlight or hot places. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.

c) Don't expose the product to extremely cold area. It may damage the internal circuit board.

d) Don't try to disassemble the product as it may get damaged if you are not professional. The internal circuit might get damaged.

f) Don't use intensive chemical products or detergent to clean the product.

g) Don't scratch the surface with sharp tips.

easym.com.br

/easymobile.br

@easy.mobile

Product support:

Email: **support@easym.com.br**